

SLR Camera Size

Lens

Maximum Diameter = 80mm / 3.2in

Maximum Length = 100mm / 4in

Body

Maximum Width = 145mm / 5.75in

Maximum Height = 120mm / 5in

Maximum Depth = 72mm / 2.8in

Please note that this is not an exact science, since the case is soft and malleable - there is a few mm tolerance.

Fit Guide - Please find your camera, or one of a similar size below:

Please note that you cannot use a flash in or through an Aquapac case

Canon

Canon EOS Digital Rebel XTi - Fits

Canon EOS Digital Rebel XSi - Fits

Canon EOS Digital Rebel XT (and other) - Fits

Canon EOS 350D - Fits

Canon EOS 40D - Fits (tight)

Canon EOS 400D - Fits

Canon EOS 450D - Fits

Canon EOS 50D - Fits (tight)

Canon EOS 5D - Does not fit

Canon EOS 5D mkII - Does not fit

Canon EOS 1D - Does not fit

Canon EOS 1000D - Fits

Canon SX 20 IS - Fits

Canon S5 IS - Fits

Nikon

Nikon D3 - Does not fit

Nikon D3X - Does not fit

Nikon D300 - Does not fit

Nikon D40 - Fits

Nikon D60 - Fits

Nikon D80 - Fits (tight)

Nikon D700 - Does not fit

Nikon D90 - Fits

Fuji

Fujifilm Finepix S5 - Does not fit

Fujifilm Finepix S700 - Fits

Olympus

Olympus E-3 - Fits (tight)
Olympus E-410 - Fits
Olympus E-30 - Fits (tight)
Olympus E-420 - Fits
Olympus E-510 - Fits
Olympus E-520 - Fits

Panasonic

Panasonic Lumix DMC-100 - Fits
Panasonic Lumix DMC FZ38 - Fits

Pentax

Pentax K100D Super - Fits
Pentax K110D - Fits
Pentax K20D - Fits (tight)
Pentax K-m - Fits

Samsung

Samsung GX10 - Fits (tight)
Samsung GX20 - Fits (tight)

Sony

Sony Alpha 200 - Fits
Sony Alpha 350 - Fits
Sony Alpha 700 - Fits (tight)
Sony Alpha 900 - Does not fit
Sony DSC-HX1 - Fits